



# BARNSTABLE FIRE DISTRICT WATER DEPARTMENT

1841 Phinney's Lane  
P.O. Box 546  
Barnstable, Massachusetts 02630  
Phone: 508-362-6498  
Fax: 508-362-9616

## Demolition Procedure

If there is a water meter inside the property, we need to gain access to the meter (usually inside the basement) to disconnect, remove and store the meter and electronic reading device. If not removed and stored the customer or contractor will be financially responsible for the replacement cost, tax and labor of new equipment.

In order for a District customer to obtain a demolition permit through the Town of Barnstable, the customer must contract (hire on their behalf) a District approved contractor to disconnect their water service. Once the service has been disconnected, the contractor must contact us (BEFORE THEY HAVE BACKFILLED) in order that we may inspect it.

Once we have inspected the disconnected water service, we will provide a letter confirming such and the customer can take that letter to the Town for the demolition permit.