



BARNSTABLE FIRE DISTRICT WATER DEPARTMENT

1841 Phinney's Lane
P.O. Box 546
Barnstable, Massachusetts 02630
Phone: 508-362-6498
Fax: 508-362-9616

Demolition Procedure

If there is a water meter inside the property, we need to gain access to the meter (usually inside the basement) to disconnect, remove and store the meter along with the electronic reading device (this device is wire to the meter but usually attached outside the home). If not removed and stored the customer or contractor will be financially responsible for the replacement cost, tax and labor of new equipment.

In order for a District customer to obtain a demolition permit through the Town of Barnstable, the customer must contract (hire on their behalf) a District approved contractor to disconnect their water service. Once the service has been disconnected, the contractor must contact us (BEFORE THEY HAVE BACKFILLED) in order that we may inspect it. Once we have inspected the disconnected water service, we will provide a letter confirming such and the customer can take that letter to the Town for the demolition permit at the Town of Barnstable offices on Main Street, Hyannis.